

# Town of Bourne

## Nitrogen Loading Calculation Sheet for Residential Housing

The following calculation sheet is based upon Technical Bulletin 91-001 issued by the Cape Cod Commission and deals with nitrate nitrogen (NO3-N) Use the information from your PLAN OF RECORD to provide the following:

### 176 Scraggy Neck Road - Proposed Conditions

Number of Bedrooms (Title 5 Definition)	=	4	Bedrooms
Lot Size (in square feet of upland areas)	=	87,006	sq.ft.
Impervious Surfaces;**roof area=	4,317	sq.ft.	**Paved Area = - sq.ft.
Natural Area = lot area minus all impervious surfaces	=	82,689	sq.ft.
Lawn Area in sq. ft.	=	6,583	sq.ft.

TITLE 5 FLOW = 110 GAL./ DAY PER BEDROOM

### WASTEWATER FLOWS (NITROGEN LOAD & WATER LOAD)

Nitrogen from Title 5 design = 14,572 mg NO3-N / day / bedroom: or 7911 mg NO3-N / day/ bedroom with IA Treatment

Water from Title 5 design = 416.3 H2O / day / bedroom

1a) Number of bedrooms = 4 x 7911 = 31644.00 mg. NO3-N / day

1b) Number of bedrooms = 4 x 416 = 1664.00 L H2O / day

Actual Nitrogen load = 6071.5 mg NO3-N / day/ bedroom: 3296 mg NO3-N / day/ bedroom with IA Treatment

Actual Water load = 173.5 L H2O / day / bedroom

\*Note: This assumes 2.5 people / unit average occupancy within the Town

2a) Number of bedrooms = 4 x 3296 = 13184.00 mg. NO3-N / day

2b) Number of bedrooms = 4 x 173.5 = 694.00 L H2O / day

### IMPERVIOUS SURFACES (NITROGEN LOAD & WATER LOAD)

NO3-N load number sq. ft. of roof surface X 0.19395 mg NO3-N / sq. ft.

H2O load number sq. ft. of roof surface X 0.2586 L / sq. ft.

3a) Roof surface = 4317 sq. ft. X 0.19395 = 837.28 mg NO3-N

3b) Roof surface = 4317 sq. ft. X 0.2586 = 1116.38 L H2O / day

NO3-N load number sq. ft. of paved surface X 0.388 mg / sq. ft.

H2O load number sq. ft. of paved surface X 0.2586 L / sq. ft.

4a) NO3-N = - sq. ft. paved surface X 0.388 mg / sq. ft. 0.00 mg NO3-N

4b) H2O = - sq. ft. paved surface X 0.2586 L / sq. ft. 0.00 L H2O

LAWN NITROGEN LOADING = 0.933 mg / sq. ft. lawn surface

$$5) \text{ sq. ft. of lawn} = 6583 \times 0.933 = 6141.94 \text{ mg}$$

NATURAL AREA WATER LOADING

$$\text{Natural area} = \text{lot size} - \text{impervious surfaces} = 82689 \text{ sq. ft.}$$

$$6) \text{ Natural area} = 82689 \times \text{water recharge factor} = 11229.17 \text{ L} \\ \text{(0.1358 L / sq. ft. for Bourne)}$$

### SUMMARY OF NITROGEN LOADING

#### Estimated Title 5 Nitrogen & Water Loading

7a) ADD the above NO<sub>3</sub>N load

1a	(+)	3a	(+)	4a	(+)	5	
31644		837.28		0.00		6141.94	38623.22 mg NO <sub>3</sub> -N / day

7b)

1b	(+)	3b	(+)	4b	(+)	6	
1664		1116.38		0.00		11229.17	14009.54 L H <sub>2</sub> O / day

7c) DIVIDE 7a by 7b = 2.8 ppm NO<sub>3</sub>-N\*\*\*\*\*

#### Actual Nitrogen & Water Loading

8a) ADD the above NO<sub>3</sub>N load:

2a	(+)	3a	(+)	4a	(+)	5	
13184		837.28		0.00		6141.94	<u>20163.22</u> mg NO <sub>3</sub> -N / day

8b) ADD the above water (H<sub>2</sub>O) load:

2b	(+)	3b	(+)	4b	(+)	6	
694		1116.38		0.00		11229.2	<u>13039.54</u> L H <sub>2</sub> O / day

8c) DIVIDE 8a by 8b = 1.5 ppm NO<sub>3</sub>-N\*\*\*\*\*

FINAL CALCULATION ADD 7c & 8c (ppm) = 4.3 divide by 2 = 2.2 ppm NO<sub>3</sub>-N

This is the actual nitrate nitrogen load for the project as designed. The target for coastal areas is 5 ppm nitrate nitrogen. Certain critical embayments may require a LOWER figure to prevent degradation.

\*\*\*\*\*If your nitrate nitrogen load exceeds the target limit **USE A SECOND CALCULATION SHEET TO SHOW ALTERNATIVES IN TRYING TO ACHIEVE THE 5 PPM NITRATE NITROGEN LEVEL**\*\*\*